
ASSEMBLY INSTRUCTIONS



2. Adjuster bolt is (under table frame extension) to line up/level off the table top, if required